

# WARRENDER, LTD.

This chart shows the proper components required for ordering "**WMT-SP**" series standard Self-Priming Thermoplastic Regenerative Turbine Pumps.

To order simply:  
Select the series and size pump you need from the brochures and performance curves.  
Then select one option from each of the 6 categories shown in the column below and write its code after the series & size designation.

ORDERING EXAMPLE  
**WMT-SP 5503 P 2 F 1**



## CATEGORY SELECTION:

### SERIES:

#### WMT-SP

Self-Priming Thermoplastic Turbine Pumps.

### SIZE:

2503  
3502  
3503  
5502  
5503  
7502  
7503  
9502  
9503  
12502  
12503  
16502  
16503

### MATERIAL:

P- Polypropylene  
V- PVDF ( Kynar )  
F- PVF ( Polypropylene Head / PVDF Internals )

### MAGNETIC COUPLING:

1 - Ferrite  
2 - Samarium Cobalt

### PORTS:

T- FNPT Threaded  
F- ANSI 150# Flanges  
H- \* Hose Barbs

### MOTOR DRIVE:

1- TEFC, Close-Coupled, 3 phase  
2- \* TEFC, Closed-Coupled, 1 phase  
3- UL-EXP, Close-Coupled, 3 phase  
4- \* UL-EXP, Close-Coupled, 1 phase  
5- Bearing Pedestal for Base Mounting  
6- Complete Close Coupled pump, less motor

For Specific Materials of Construction Refer to Production Code Sheet.